

General Safety Information

⚠ WARNING – To avoid serious injuries:

- Use the cleat covers only for genuine Shimano cleats (SM-SH10/SM-SH11).
- To keep the original attachment/detachment performance, remove any mud, dirt, or foreign materials stuck on the cleat and cleat cover.
- Riding the bicycle with the cleat cover attached may cause your feet to slip off the pedals and cause you to fall down, resulting in serious injury.
- Because wet and/or smooth surfaces are very slippery, use extreme caution when walking on such surfaces in order to avoid serious injury.
- Walking with the cleat covers attached to abraded cleats may cause the covers to detach unexpectedly and cause you to fall down, resulting in serious injury.
- **Read the service instructions carefully prior to installing the parts and follow them.**
- Read these Technical Service Instructions carefully, and keep them in a safe place for later reference.
- If you have any questions regarding methods of installation, adjustment, maintenance or operation, please contact a professional bicycle dealer.

- Failure to observe the above instructions may cause the cleat covers to detach unexpectedly and cause you to fall down, resulting in serious accident.

NOTE:

- The cleat covers are designed to protect the cleats.
- The cleat covers are not designed to protect shoe soles. Do not step on sharp pointed objects or apply impact shock to soles because soles are made of special materials.
- Do not use washing machines or dryers to clean the cleat covers.
- Dry the cleat covers in the shade without using a dryer or similar appliance that applies heat.
- Do not leave the cleat covers exposed to the environment at 50°C or higher; doing so may cause the cleat covers to become deformed.
- Parts are not guaranteed against natural wear or deterioration resulting from normal use.


SM-SH45

Cleat cover

Types of usable cleats


SM-SH10

Wide



SM-SH11

Narrow




Note:


- The cleat covers are designed in the same shape to be used with both right and left cleats.
- Because the cleat covers are consumable parts, it is necessary to replace them periodically.

Use method

■ Attachment method



■ Removal method



* Service Instructions in further languages are available at :
<http://techdocs.shimano.com>

Please note: Specifications are subject to change for improvement without notice. (English)

SHIMANO

SHIMANO AMERICAN CORPORATION

One Holland, Irvine, California 92618, U.S.A. Phone: +1-949-951-5003

SHIMANO EUROPE B.V.

Industrieweg 24, 8071 CT Nunspeet, The Netherlands Phone: +31-341-272222

SHIMANO INC.

3-77 Oimatsu-cho, Sakai-ku, Sakai-shi, Osaka 590-8577, Japan

© Oct. 2009 by Shimano Inc. AWS. IZM. Printed in Malaysia