









1	Air Release Button (works with Schrader Valve only)						
2	Dial Gauge (0-300 psi/ 0-20.7 bar)						
3	Rotating Hose 						
4	Inflation Mode Selection <table border="0" style="display: inline-table; vertical-align: middle;"> <tr> <td style="text-align: center;">MTB TIRE mode</td> <td style="text-align: center;">↔</td> <td style="text-align: center;">SHOCK/FORK mode</td> </tr> <tr> <td style="text-align: center;">  </td> <td></td> <td style="text-align: center;">  </td> </tr> </table>	MTB TIRE mode	↔	SHOCK/FORK mode			
MTB TIRE mode	↔	SHOCK/FORK mode					
							
5	High polish Aluminum Barrel						
6	Hose Dock						
7	SmartHead™ ThreadLock fits both Presta and Schrader valves <table border="0" style="display: inline-table; vertical-align: middle;"> <tr> <td style="text-align: center;">Schrader Mode</td> <td style="text-align: center;">Presta Mode</td> </tr> <tr> <td style="text-align: center;">  </td> <td style="text-align: center;">  </td> </tr> </table>	Schrader Mode	Presta Mode				
Schrader Mode	Presta Mode						
							
8	Vent Hole *						

### \* NOTE of Vent Hole


A small amount of air pressure will escape from the vent hole when inflating suspension fork or rear shock. It's normal and won't affect inflation.

DO NOT block the vent hole while inflating in Shock Mode. Doing so will adversely affect inflation.




### NOTE

- Before using Shock 'n Roll to inflate your suspension fork or rear shock, check and do not exceed factory recommended pressures.
- Make sure to choose the correct Inflation Mode (Tire Mode or Shock Mode) before engaging pump valve to the valve stem. DO NOT switch Inflation Mode when the pump valve is still engaged on valve stem to avoid the leakage of air.




### TIRE MODE




### SHOCK MODE (Schrader mode)

#### ENGAGE



#### DISENGAGE



#### WARRANTY

2-year Warranty: All mechanical components against manufacturer defects only.

##### Warranty Claim Requirements

To obtain warranty service, you must have your original sales receipt. Items returned without a sales receipt will assume that the warranty begins on the date of manufacture. All warranties will be void if the product is damaged due to user crash, abuse, system alteration, modification, or used in any way not intended as described in this manual.

\* The specifications and design are subject to change without notice.

Please contact your Topeak dealer with any questions.

For USA customer service call : 1-800-250-3068  
www.topeak.com